



FÜRSTENBERG

— 1747 —



– KOLLEKTION –

CARLO DAL BIANCO


Preise *prices*

Stand Januar 2010 *last updated January 2010*

For more Lifestyle

ARTIKEL <i>article</i>	ORDER-NR. <i>order-no.</i>	WEISS <i>white</i>	ESTE DEKOR <i>pattern 5900</i>	ORO DEKOR <i>pattern 5901</i>	PLATINO DEKOR <i>pattern 5902</i>
 Broteller, ø 16 cm <i>bread plate</i>	FL 201116	15,00	52,00	36,00	36,00
 Frühstücksteller, ø 23 cm <i>breakfast plate</i>	FL 201123	21,00	59,00	49,00	49,00
 Gourmetteller klein, ø 23 cm <i>gourmet plate small</i>	FL 2011G3	29,00	65,00	52,00	52,00
 Gourmetteller groß, ø 29 cm <i>gourmet plate large</i>	FL 2011G9	36,00	89,00	68,00	68,00
 Speiseteller, ø 29 cm <i>dinner plate</i>	FL 201129	36,00	75,00	65,00	65,00
 Platzteller, ø 32 cm <i>service plate</i>	FL 201132	40,00	133,00	95,00	95,00
 Suppenteller, ø 23 cm <i>soup plate</i>	TF 201122	29,00	69,00	59,00	59,00
 Pastateller, ø 26 cm <i>pasta plate</i>	TF 201126	36,00	79,00	69,00	69,00
 Suppen-Obertasse, 0,32 l  Suppen-Untertasse, ø 21 cm <i>soup cup, saucer</i>	OB 201120 UN 201120	45,00 18,00	89,00 55,00	79,00 35,00	79,00 35,00
 Dessertschale, ø 13 cm <i>fruit saucer</i>	KO 201116	42,00	79,00	66,00	66,00

ARTIKEL <i>article</i>	ORDER-NR. <i>order-no.</i>	WEISS <i>white</i>	ESTE DEKOR <i>pattern 5900</i>	ORO DEKOR <i>pattern 5901</i>	PLATINO DEKOR <i>pattern 5902</i>
 <p>Cloche, ø 13 cm <i>cloche</i> passend für Suppen-Obertasse, Dessertschale, Schüssel rund 13 cm <i>suitable for soup cup, fruit saucer, bowl 13 cm</i></p>	CL 201113	42,00	54,00	52,00	52,00
 <p>Sauciere 2-tlg., 0,40 l <i>sauceboat, saucer</i></p>	SA 2011	88,00	165,00	138,00	138,00
 <p>Schüssel rund, ø 13 cm Schüssel rund, ø 18 cm Schüssel rund, ø 23 cm Schüssel rund, ø 26 cm <i>bowl</i></p>	SL 201113 SL 201118 SL 201123 SL 201126	24,00 55,00 69,00 95,00	59,00 99,00 126,00 270,00	39,00 79,00 89,00 123,00	39,00 79,00 89,00 123,00
 <p>Platte oval, 32 cm Platte oval, 36 cm <i>platter oval</i></p>	OV 20111 OV 20112	58,00 89,00	110,00 155,00	105,00 129,00	105,00 129,00
 <p>Espresso-Obertasse, 0,10 l Espresso-Untertasse, ø 13,5 cm <i>espresso cup, saucer</i></p>	OB 20117 UN 20117	27,00 11,00	69,00 39,00	49,00 29,00	49,00 29,00
 <p>Kaffee-Obertasse, 0,20 l <i>coffee cup</i></p>	OB 20115	31,00	69,00	57,00	57,00
 <p>Tee-Obertasse, 0,22 l <i>tea cup</i></p>	OB 201115	37,00	75,00	69,00	69,00
 <p>Cappuccino-Obertasse, 0,26 l <i>cappuccino cup</i></p>	OB 20119	30,00	79,00	59,00	59,00
 <p>Schokoladen-Obertasse, 0,32 l <i>hot chocolate cup</i></p>	OB 201119	36,00	89,00	68,00	68,00
 <p>Universaluntertasse, ø 16 cm <i>saucer</i> passend für Kaffee-, Tee-, Cappuccino-, Schokoladen-Obertasse, Zuckerdose, Milchkännchen <i>suitable for coffee, tea, cappuccino, hot chocolate cup, sugar box, creamer</i></p>	UN 20115	13,00	38,00 DEKOR pattern 5900/1 38,00	29,00	29,00

ARTIKEL <i>article</i>	ORDER-NR. <i>order-no.</i>	WEISS <i>white</i>	ESTE DEKOR <i>pattern 5900</i>	ORO DEKOR <i>pattern 5901</i>	PLATINO DEKOR <i>pattern 5902</i>
 Teekanne, 0,80 l <i>teapot</i>	TK 20113	129,00	199,00	179,00	179,00
 Teesiebbehälter <i>tea strainer beaker</i>	OB 201110	30,00	85,00	72,00	72,00
 Stövchen 2-tlg. <i>rechaud</i>	TW 2011	65,00	110,00	82,00	82,00
 Zuckerdose, 0,20 l <i>sugar box</i>	ZD 20113	65,00	120,00	105,00	105,00
 Milchkännchen, 0,20 l <i>creamier</i>	GI 20113	53,00	85,00	72,00	72,00
 Milch-/Zuckerplateau, ø 19 cm <i>milk/sugar tray</i>	ZU 2011	56,00	99,00	85,00	85,00
 Eierbecher <i>egg-cup</i>	EI 2011	15,00	44,00	25,00	25,00
 Salzstreuer <i>salt-shaker</i>	SZ 2011	28,00	–	36,00	36,00
 Pfefferstreuer <i>pepper-shaker</i>	PF 2011	28,00	–	36,00	36,00
 Serviettenring <i>napkin holder</i>	SV 2011	39,00	–	89,00	89,00