



FÜRSTENBERG

— 1747 —














TAPA

Preise *prices*

Stand April 2010 *last updated April 2010*











For more Lifestyle

| ARTIKEL <i>article</i> | ORDER-NR. <i>order-no.</i> | WEISS <i>white</i> |
|---|-------------------------------|-----------------------|
|  Brotteller , ø 15 cm Brotteller , ø 17 cm <i>bread plate</i> | FL 200515 FL 200517 | 15,50 17,50 |
|  Frühstücksteller , ø 19 cm <i>breakfast plate</i> | FL 200519 | 20,00 |
|  Speiseteller , ø 24 cm Speiseteller , ø 29 cm <i>dinner plate</i> | FL 200524 FL 200529 | 29,50 33,50 |
|  Platzteller , ø 32 cm <i>bottom plate</i> | FL 200532 | 38,50 |
|  Suppenteller , ø 22 cm <i>soup plate</i> | TF 200522 | 23,00 |
|  Pastateller , ø 28 cm <i>pasta plate</i> | TF 200528 | 36,50 |
|  Suppentasse, klein 2-tlg. , 0,25 l <i>soup cup, saucer</i> | TA 200521 | 36,00 |
|  Suppentasse, groß 2-tlg. , 0,35 l <i>soup cup, saucer</i> | TA 200520 | 39,00 |
|  Suppenschale , 17 x 11 x 4,5 cm <i>soup bowl</i> | SC 200518 | 32,50 |
|  Schale , 17 x 5,5 cm <i>bowl</i> | SC 200517 | 23,50 |
|  Schale , 22 x 7 cm <i>bowl</i> | SC 200522 | 26,50 |

Unverbindliche Preisempfehlung (Preise in €) *recommended retail prices (prices in €)*

| ARTIKEL <i>article</i> | ORDER-NR. <i>order-no.</i> | WEISS <i>white</i> |
|--|-------------------------------------|-------------------------|
|  Schale , 22 x 11,5 cm <i>bowl</i> | SC 200523 | 30,00 |
|  Schale , 29 x 9,5 cm <i>bowl</i> | SC 200529 | 34,50 |
|  Schale , 32 x 21 cm <i>bowl</i> | SC 200532 | 63,50 |
|  Schale , 50 x 16 cm <i>bowl</i> | SC 200550 | 77,50 |
|  Löffel , 11 x 4 cm <i>spoon</i> | SC 200511 | 18,00 |
|  Gießer , 9 x 6 x 6,5 cm <i>creamer</i> | GI 20052 | 24,00 |
|  Gießer mit Griff , 9 x 6 x 6,5 cm <i>creamer with grip</i> | GI 2005 | 27,50 |
|  Dippschale , ø 6 cm Dippschale , ø 9 cm <i>small dish</i> | KO 20056 KO 20059 | 9,00 15,00 |
|  Schüssel , ø 13 cm Schüssel , ø 17 cm Schüssel , ø 21 cm <i>bowl</i> | SL 200513 SL 200517 SL 200521 | 29,00 38,50 69,50 |

Spülmaschinenfest *dishwasher-proof*

| ARTIKEL <i>article</i> | ORDER-NR. <i>order-no.</i> | WEISS <i>white</i> |
|---|-------------------------------|-----------------------|
|  <p>Mokka-/Espressotasse 2-tlg., 0,08 l <i>mocha/espresso cup, saucer</i></p> | TA 20057 | 30,50 |
|  <p>Kaffee-/Teetasse 2-tlg., 0,20 l <i>coffee/tea cup, saucer</i></p> | TA 20055 | 33,00 |
|  <p>Cappuccinotasse 2-tlg., 0,25 l <i>cappuccino cup, saucer</i></p> | TA 20056 | 33,00 |
|  <p>Frühstückstasse 2-tlg., 0,35 l <i>breakfast cup, saucer</i></p> | TA 20059 | 39,00 |
|  <p>Kaffee-/Teekanne, 0,45 l Kaffee-/Teekanne, 1,20 l <i>coffee-/teapot</i></p> | KK 20051 KK 20053 | 95,50 114,00 |
|  <p>Stövchen, ø 13 cm <i>rechaud</i></p> | TW 200513 | 88,00 |
|  <p>Zuckerdose, 0,07 l <i>sugar box</i></p> | ZD 20052 | 27,00 |
|  <p>Marmeladendose, 0,20 l <i>jam box</i></p> | MD 20055 | 44,00 |
|  <p>Milchkännchen, 0,07 l Milchkännchen, 0,25 l <i>creamers</i></p> | GI 200522 GI 20056 | 20,00 30,00 |
|  <p>Eierbecher, 4,5 cm <i>egg-cup</i></p> | EI 2005 | 12,50 |